


Extension Kit

VE100K





ENGLISH

Dustbuster[®] Extension Kit VE100K

Thank you for choosing Black & Decker. We hope that you will enjoy using this product for many years.

OVERVIEW

- 1. Connector
- 2. Upper tube
- 3. Lower tube
- 4. Floor head
- 5. Brush actuator switches

INTENDED USE

Your Black & Decker Dustbuster® Extension Kit has been designed to aid light dry vacuum cleaning of hard floors, rugs and carpets. The Extension Kit fits the following 4.8 V, 7.2 V and 9.6 V Dustbuster® models: V4800, V4810, V4820, V7210, V9650. This product is intended for household use only.

SAFETY INSTRUCTIONS

When using the Extension Kit with your Dustbuster[®], follow the safety instructions described in the Dustbuster[®] manual.

ASSEMBLY

- Fit the connector (1) on to the nose of the appliance.
- Fit the upper (2) and lower (3) tubes together and attach the floor head (4) to one end of the tube.
- Attach the other end of the tube to the connector on the nose of the appliance.
- Alternatively, to use as a hand-held cleaner with brush on stairs and furniture, attach the floor head directly on to the connector.

USE

- Switch the Dustbuster[®] on.
- Use the switches (5) on the floor head (4) to lower or raise the bristles on the brush.
 - Lower the bristles for cleaning carpets or rugs.
 - Raise the bristles for cleaning hard floors, such as wood, tile or marble.

Protecting the environment

Black & Decker provides a facility for recycling Black & Decker products once they have reached the end of their working life. This service is provided free of charge. To take advantage of this service please return your product to any authorised repair agent who will collect them on our behalf.

You can check the location of your nearest authorised repair agent by contacting your local Black & Decker office at the address indicated in this manual. Alternatively, a list of authorised Black & Decker repair agents and full details of our after-sales service and contacts are available on the Internet at: www.2helpU.com.

GUARANTEE

Black & Decker is confident of the quality of its products and offers an outstanding guarantee. This guarantee statement is in addition to and in no way prejudices your statutory rights.

ENGLISH

The guarantee is valid within the territories of the Member States of the European Union and the European Free Trade Area.

If a Black & Decker product becomes defective due to faulty materials, workmanship or lack of conformity, within 24 months from the date of purchase, Black & Decker guarantees to replace defective parts, repair products subjected to fair wear and tear or replace such products to ensure minimum inconvenience to the customer unless:

- The product has been used for trade, professional or hire purposes;
- The product has been subjected to misuse or neglect;
- The product has sustained damage through foreign objects, substances or accidents;
- Repairs have been attempted by persons other than authorised repair agents or Black & Decker service staff.

To claim on the guarantee, you will need to submit proof of purchase to the seller or an authorised repair agent. You can check the location of your nearest authorised repair agent by contacting your local Black & Decker office at the address indicated in this manual. Alternatively, a list of authorised Black & Decker repair agents and full details of our after-sales service and contacts are available on the Internet at: www.2helpU.com.

Australia	DEWALT Industrial Power Tool Company 7 Clarice Road, Box Hill, Victoria 3128	Tel. 03 9895 9200 Fax 03 9899 7465
New Zealand	Black & Decker	Tel. 09 579 7600
	81 Hugo Johnson Drive	Fax 09 579 8200
	Penrose, Auckland, New Zealand	
South Africa	Black & Decker South Africa (Pty) Ltd	Tel. (011) 653-1400
	Physical address:	Fax (011) 653-1499
	39 Commerce Crescent	
	Eastgate, ext. 12, Sandton, Kramerville 2148	
	Postal address:	
	Postnet Suite 107, Private Bag X65	
	Halfway House 1685	
United Kingdom	Black & Decker	Tel. 01753 511234
•	210 Bath Road	Fax 01753 551155
	Slough, Berkshire SL1 3YD	Helpline 01753 574277

Dealer address	Date of purchase
· · · · · · · · · · · · · · · · · · ·	Was this tool bought as a replacement?
Address:	Ves No
Town:	
Postal code:	Dealer address:
Was this tool a gift?	
Ves No	Data protection act: Tick the box if you prefer not to receive further information.

•

Was this tool your first purchase?



country. If you live in Australia or New Zealand, please register by using the alternative guarantee card supplied. Please complete this section immediately after the purchase of your tool and send it to Black & Decker in your . . .

GUARANTEE CARD